

STANDARD / CLARITY SNEEZE SCREENS

PROTECTIVE FILM COVERS

All our sneeze screens come with a protective film on both sides of the Acrylic. Please remove these prior to use.

FITTING INSTRUCTIONS

All our Sneeze screens are acrylic formed and although some versions maybe free standing, we always reccomend they are fixed to your counter or desk with a High bond Double Sided Tape (ideally a Gel Tape), or screwing using 2 or 4 fixing points. **If you are using a Double Sided Tape, please ensure the whole base is covered to maximise surface adhesion.**

For Screwing, please use a sharp metal drill bit for your pilot hole, and using a drill at high speed drill slowly through the acrylic base ideally also using masking tape over the hole before you start. You should always drill a pilot hole (approx 4-5mm) before you screw into the counter using screws. Do not over tighten the screws.

CLEANING and AFTERCARE

The Acrylic Screens are durable to most cleaning chemicals and should be cleaned with a soapy water solution or window cleaner spray.

