

TEMPEST WATER BASE PAVEMENT SIGN A1

Assembly Guide

STEPS:

1. Kit includes: Snap frame, moulded base and 2x bolts.
2. Insert the snap frame springs into the moulded base.
3. Insert bolt and washer through the top of the moulded base.
4. Tighten the bolt to secure the snap frame to the moulded base. Repeat steps 3 and 3 for the second bolt.
5. Open up the snap frame sides.
6. Remove the protective cover.
7. Fit the graphic into the snap frame
8. Fit the protective cover.
9. Close the snap-frame to hold the graphics in place.

Note: When moving the unit do not drag the base. Tip unit onto it's wheels and pull or push to move

