

RHINO[®] BRANDED GAZEBO

ASSEMBLY INSTRUCTIONS

INSTRUCTIONS:

- 1) Remove bag and stand 2 people on opposite sides
- 2) Grasp legs & pull backwards to part-extend frame
- 3) Add canopy & secure each corner with Velcro fixings
- 4) Fully extend frame outwards until locking arm clicks
- 5) Turn crank to fully tension the roof pitch
- 6) Secure canopy to frame with Velcro tabs
- 7) Push button to increase height on each leg
- 8) Repeat for all four legs, one side at a time
- 9) Attach walls using Velcro strips along the top
- 10) Slide on gazebo weights (one per leg)

