



FRONTIER OFFICE SCREEN LINKING INSTRUCTIONS




1

Carefully unwrap screens and position first screen where required.
Remove top cap to reveal inline link.




2

Slide inline link out of the sides you wish to link.




3

To form an inline link, align the screens as shown.




4

Slide inline link in between the side trims as shown to link the screens.




5

Ensure link is flush with the side trims and then replace the top caps.




6

To join at 90°, 3 or 4 way a junction post is required.




7

Remove top caps and inline link and position as shown.



8

Slide inline link all the way down in between the junction post and screen side trim to join, ensuring link is flush with the top.



9

Repeat step 8 for remaining screens to create desired configuration. To finish replace top caps.